



PLUMAS COUNTY LIBRARY

T10 HOTSPOT INSTRUCTIONS

To turn your hotspot on or off, press and hold the **Power Button** on the front of the device for at least two seconds.

Your hotspot has a series of screens that let you view device information and system alerts. Press the **Power Button** (Navigation Key) to cycle through the following:



	Press  quickly	Home screen, Device menu guide (switching every 3 seconds)
	Press  quickly	Wi-Fi Name display
	Press  quickly	Password display
	Press  quickly	Back to Home screen

Visit your local library if you need help. If possible, bring the device you are trying to connect to with the hotspot so Library Staff can provide support.